



# HP Envy 23-d060qd TouchSmart Back Panel Replacement

This guide will demonstrate how to properly remove the back panel on the HP Envy 23-d060qd TouchSmart. This guide is a prerequisite for all other guides.

Written By: Zachary Dicks





## TOOLS:


- [Phillips #2 Screwdriver](#) (1)
-

## Step 1 — Back Panel



- Use your hands to unclip the plastic snaps on the back panel of the device.

## Step 2



- Remove the three 11.5mm PH2 screws from the back panel.
- ⓘ The screws will not fall out of the back panel, but they will unscrew to release the back panel.

## Step 3



- Now, take the back panel off by pulling at it gently with your hands.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-26 11:18:54 PM.